
SWING GATE ONLY
OR
Y/WH
BL/WH
C SHADOW NO NC
C OP L/S NO NC
NO C L/S C NC
BRAKE RSG ONLY (WHEN REQUIRED)
R → TO SHADOW LOOP DETECTOR
BL → TO TERMINAL 11
CHASSIS GROUND
MOTOR CONTROL CIRCUIT BOARD
8 SOCKET HV HARNESS
115V SOLENOID
115
GY
BK/WH
BK
BL
MSW ONLY
70MFD 220V
M1
M2
MOTOR
GRD
WH
BR
24 VAC
XFMR
FUSE
WIRING BOX
POWER SWITCH
HOT LEG
NEUTRAL
LINE 115V 1Ø
RADIO
R1
R2
R3
R4
RADIO TERMINAL STRIP
GSMCB-02 P.C. BOARD
NOT USED
24 VAC FOR ACCESSORIES
SINGLE BUTTON
RADIO OPEN
FREE EXIT
STOP
COMMON
OPEN
CLOSE
COMMON
REVERSE
OPEN PHOTO
CLOSE PHOTO
OPEN EDGE
CLOSE EDGE
COMMON
*FOR MASTER/SLAVE WIRING ONLY! (SEE INSTRUCTIONS)
WIRED FOR 115V, 1 Ø
*FOR MASTER/SLAVE WIRING ONLY! SEE INSTALLATION MANUAL.
UNITS SHIPPED AS RIGHT HAND.
FOR LEFT HAND SEE INSTRUCTION MANUAL.
PowerMaster
FOR USE WITH: 2000 SERIES OPERATOR WITH GSMCB-02 BOARD
DATE: 1/3/05
REV. 5
BY: F.S.
RSG, RSW, MSW
CONTROL WIRING DIAGRAM
WIRING DIAGRAM 6002
© Copyright PowerMaster 2006
No portion of this diagram may be reproduced without the expressed written permission of the manufacturer.