



**WIRED FOR
208/230V, 1 Ø**

PowerMaster	
FOR USE WITH: SG 2004 SERIES OPERATOR WITH UMCB-01 BOARD AND CONTACTOR CAP START MOTOR	
DATE: 8/3/05	REV. 3
BY: F.S.	SG
CONTROL WIRING DIAGRAM	
WIRING DIAGRAM 6102	
© Copyright PowerMaster 2006 No portion of this diagram may be reproduced without the expressed written permission of the manufacturer.	